



INSTALLING CASTERS (A)

1. Place the unit on its side. Make sure that the lock is engaged on the casters and screw them into the four holes on the bottom side on the unit.



INSTALLING HANDLE (B)

1. Determine which side of the unit you want to install the handle on and remove the two small black caps from that side. Squeeze the sides of the cap and push it out at the same time. Leave the two small black caps on the other side in the unit.

2. Align the handle over the holes with one hand and reach inside the unit to insert the screws and washers with the other hand.

NOTE: If you plan to stack two units, install the handle on the top unit.

STACKING TWO CHARGING STATIONS

1. Remove the black caps from the four larger holes in the top of the bottom unit. Squeeze the sides of the cap and push it out at the same time. **(C)**

2. Place the second unit on its side and insert the four rubber feet if they are not already installed.

3. Place the second unit on top of the first unit. Line up the holes in the bottom side of the top unit with the four larger holes in the top side of the bottom unit.

4. Insert the stacking screws into the holes from inside of the bottom unit. Screw in all four partially at first and, when they are all in, tighten them the rest of the way. **(D)**

