
UNIVERSAL USB-C CHARGING DOCK

JAR SYSTEMS


FEATURING QUICK-SENSE CHARGING TECHNOLOGY

Model: QC-8000 Manual Version B


SETUP




Insert dividers into slots on the top of the dock.



Push dividers backward to lock in place.



Plug the USB-C to USB-C charging cables that come with the charging dock into the charging ports.



Lift the dock up to view the underside. Connect the power cable to the back of the charger.

START CHARGING!

Plug the power cable into a standard 15A outlet. LEDs will illuminate white to indicate the dock is connected to a power source. Connect USB-C devices with supplied charging cables. LEDs will cycle between white, blue, and green according to the level of current being drawn by the device. Refer to the device itself for the level of charge.

Connecting Devices Without a USB-C Port: Devices that do not feature a USB-C charging port can be charged with the Universal USB-C dock using USB-C PD emulator cables available from JAR Systems. (Not Included)

IMPORTANT! Only connect laptops, Chromebooks, tablets, cell phones, and approved mobile devices. Connecting incompatible devices will void all warranties. Always observe the warnings on the back side of this manual.

WARRANTY

This product comes with a one-year warranty that covers any defects in material or workmanship and extends to the original consumer of the product only. JAR Systems LLC will replace the product with a new or refurbished product, repair the product, send replacement parts, or refund the purchase price of the product, at JAR Systems LLC's discretion. This warranty does not cover accidental damage, unreasonable use, neglect, tampering or other causes not arising from defects in material or workmanship.

Any implied warranties last only as long as the warranty periods listed above except where state law does not allow limitations on how long an implied warranty lasts. This includes but is not limited to the implied warranties or merchantability and fitness. JAR Systems LLC's responsibility is limited to the actions listed above and nothing else.

This warranty does not cover, and JAR Systems, LLC will not be responsible for, any damages due to loss of use of the product, or any other costs or expenses incurred by you or anyone else who uses the product, whether due to defects, breach of contract, negligence, strict liability or otherwise. JAR Systems is not liable for any indirect, special, incidental or consequential damages related to the product or this warranty. Some states do not allow exclusions or limitations on consequential or incidental damages, so these limitations or exclusions may not apply.

This warranty gives you specific legal rights and you may also have other rights that vary from state to state. This warranty is governed by the laws of Florida, excluding its conflict of laws principles, unless your state requires that its law be used.

WARNINGS

- · To clean and disinfect, wipe the surface with a non-abrasive, lint-free cloth and rubbing alcohol. Do not spray liquids directly onto the station or charging module.
- · Keep away from moisture. Do not place any objects filled with liquids near the charging station.
- · Do not operate in extreme temperatures. For indoor use only.
- · Children are often unaware of hazards associated with electrical devices and the station and charging module must, therefore, always be used by an adult or with adult supervision.
- · Do not connect unsupported items to the charging module or use for any purpose other than its intended use.
- · Do not attempt to dismantle, open, or make modifications to the system. Doing so will void any warranties.
- · Do not obstruct any ventilation openings.
- \cdot Do not sit or stand on the station.
- · Do not use an extension cable or daisy-chain to another device.
- · Not intended for operation at altitudes greater than 2000 m or 6561 ft above sea level.

Disclaimer: Failure to read, thoroughly understand, and follow all instructions can result in serious personal injury, damage to equipment, or voiding of factory warranty. Since the use of this information, the equipment connected, and the conditions by which any JAR Systems product is used is beyond the control of JAR Systems, it is the obligation of the owner and/or user to determine the correct and safe use of any equipment and product. To the extent that the law permits, any liability which may be incurred as a result of the use or future use of a product manufactured or sold by JAR Systems is limited to the cost of repairing or replacing the failed product or component at the discretion of JAR Systems either within, or outside of warranty periods, and does not extend to any loss or damage which may be caused as a consequence of misuse or failure of the equipment, product or the information contained herein. JAR Systems shall not in any event be liable for economic loss of profits, indirect, special, bodily injuries or consequential damages. Specifications and images are for illustration purposes only. Final product may differ and is subject to change without notice.